

Timestrip neo Instructions

- 1 Activation** To activate, press and hold the button for >3.5 seconds until the green 'Power on' LED flashes 3 times.
- 2 Activation Indication** Once the indicator has been activated, the 'Power on' LED will flash every 8 seconds.
- 3 Start Delay** The device starts monitoring temperature after the 30-minute start delay.
- 4 No Breach** If no temperature breach has occurred, the green 'Power' LED will flash.
- 5 2°C Lower Limit** When the temperature drops below 2°C for more than 30 minutes, the red '2°C' LED will flash.
- 6 -0.5°C Lower Limit** When the temperature drops below -0.5°C for more than 10 minutes, the red '-0.5°C' LED will flash.

- 7 8°C Upper Limit** When the temperature exceeds 8°C for more than 2 hours cumulative, the green '2h' LED will flash.
- 8 8°C Upper Limit** When the temperature exceeds 8°C for more than 4 hours cumulative, the green '4h' LED will flash.
- 9 8°C Upper Limit** When the temperature exceeds 8°C for more than 6 hours cumulative, the amber '6h' LED will flash.
- 10 8°C Upper Limit** When the temperature exceeds 8°C for more than 8 hours cumulative, the red '8h' LED will flash.

